


## Jasmine Turntable Motor setup instructions

The TM-R401 include a micro-controller chip on the control board, The speed adjusted by a coding switch, not by a traditional resistor switch. Each step you turn the switch change a little speed, that is the base to let the motor reach a precise speed.

Please give your patience to turn the switch more circles, you will reach the speed you want. Then, the microcontroller chip will remember the speed you setup, next time you just need to power on/off the motor.

### Setup instructions



- Step 1:
- Install the belt,
  - Put a stroboscope disc on the platter,
  - Power on the stroboscope lamp
  - power on the motor.



- Step 2:
- Turn the speed selector to the 33 1/3 rpm position.
  - Tune the speed adjustment knob till the speed reach the 33 1/3 rpm.

- Step 3: - Turn the speed selector to the 45 rpm position.  
- Tune the speed adjustment knob till the speed reach the 45 rpm.
- Setp4: - After the motor run several minutes, toggle the speed selector to confirm the speed you setup is correct and steady. If not, repeat step 2 and step3.